


Artists Brush Washer



- ① 11 oz Niblets can - Remove label & wash
- ② 15.8 oz Bean can - " " "
- ③ Punch bottom of bean can full of holes
- ④ Cut the bean can down to 1 to 2 in"
Roll cut edge to eliminate sharpness
- ⑤ Drop bean can with holes up, into the Niblets can
- ⑥ 16 oz baked bean can washed and label removed
- ⑦ Use as Lid

Keith
PAYEN